



An Excellent and Economical Powdered Extraction Cleaner

Extraction Cleaner is a powdered detergent, made primarily for truck-mounted equipment, but can be used on all portable units. Our powerful cleaner will quickly break down through tough soils, lifting them off carpet fibers.


Extraction Cleaner contains emulsifiers, surfactants, solubilizers, and corrosion inhibitors, in a pH controlled alkaline system, so it won't harm your equipment or pump.

Works in both warm or cold water, so it's compatible with no-heat portables or high-heat truck mounts.

Extraction Cleaner is powerful enough for the tough, ground-in soils on commercial carpet, but safe enough for residential.

Key Features of Extraction Cleaner

- Contains corrosion inhibitors
- Powder formula helps in cooler weather
- Safe for all generations of carpet



Extraction Cleaner (Powdered Triple Treat)



6 lb. 4/case

Extraction Cleaner (Powder)

C010-002

Diluted pH 9-9.5

DIRECTIONS: Shake well before using.
Test fabric in inconspicuous place for color fastness before using.

TO PREPARE STOCK SOLUTION:

TRUCK MOUNTS- Adding 1 to 2 quarts (946 mL - 1.89 L) of Extraction Cleaner to 5 gallons (18.9 L) of water in the concentrate tank.

PORTABLE JET EXTRACTION machines, add 1 oz. (30 mL) of Extraction Cleaner to every 1 gallon (3.785 L) of water.

Dilution ratio at the tips equals 1:128

TO CLEAN CARPETING:

1. To prepare carpet for jet extraction cleaning, vacuum or use the Model S Pile Brush to remove dry soil.
2. Run wand or nozzle over area being cleaned, jetting solution as needed. Pick up spent solution and soil by moving wand or nozzle back and forth three or four times over area sprayed.
3. Overlap previously cleaned area slightly in proceeding to uncleaned area.
4. Finish carpet with a nap brush.
5. Use furniture protectors under legs of furniture replaced on damp carpet.